



168-101-051 4,100円 ゴールドしのぎ丸蓋物(9.7×9) 1116810105



168-201-051 **4,100**円 シルバーしのぎ丸蓋物(9,7×9) 1116820105



168-301-341 **3,600円** 呉須線面取り蓋物(10×9) 1116830134



168-401-511 **3,600円** 赤釉銀彩刷毛 小煮物碗(9.8×8.2) 1116840151



169-101-511 5,250円 緑とちり 煮物碗(12×10) 1116910151



169-102-261 **5,500**円 手描き紅梅円菓子碗(12×8) 815730226



169-103-051 5,200円 黄釉色絵唐草煮物碗(12×9) 715010105



169-201-511 **5,250**円 紫とちり 煮物碗(12×10) 1116920151



169-202-051 **5,200**円 ピンク吹七宝紋蓋物(11.2×10.8×8.8) 715020105



169-203-701 **4,640**円 金唐草円菓子碗(11.5×7.8) 501520471



169-301-511 **4,000**円 緑巻金彩刷毛 小煮物碗(9,8×8.2) 1116930151



169-302-741 5,080円 彩光ライラック円菓子碗(11.5×7) 1016710374



169-303-261 **5,200**用 銀彩黄交趾円菓子碗(11.5×8.5) 815720126



169-401-511 **3,750**円 いぶし銀巻 円菓子碗(11.1×9.3) 1116940151



169-402-741 **4,400**円 赤絵七宝円菓子碗(11.9×8.3) 815730374




169-403-701 4,310円 ラスター華々蓋向(13.5×7) 815610170





170-101-741 **5,300**円 赤巻唐草玉型円菓子碗 (10.3×9.5) 501610274



170-102-741 **5,750**円 黒マット円菓子碗 (10.5×9.2) 501610177



170-103-781 **5,080**円 彩光ライラック玉型円菓子碗 (_φ10.5×9.5) 1016810378



170-104-741 **4,320**円 金唐草玉型円菓子碗 (10.5×9.5) 501620474



170-105-781 **4,860**円 黒金唐草玉型円菓子碗 (10.3×9.5) 501610477




170-201-701 **5,300**円 赤巻唐草円菓子碗 (11.5×7.8) 501520177



170-202-251 **4,750**円 金緑彩円菓子碗 (11×8.5) 501720125



170-203-071 **4,300**円 緑十草煮物碗 (11×8.5) 501610507



170-204-351 **3,750**円 マロン吹銀彩円菓子碗 (11.1×9.3) 916830235



170-205-051 **3,600**円 石面蓋物一珍ラスター (13×9.7×7) 501310305



170-301-051 **3,200**円 白刷毛目二色吹煮物碗 (11.2×9) 715420405



170-302-701 **3,260**円 吹墨玉型円菓子碗 (10.5×9.4) 501630371



170-303-071 **3,450**円 色十草円菓子碗



170-304-511 **2,400**円 二色吹 小煮物碗 (9.8×8.2) 1117030451



170-305-511 **2,400**円 三色吹 小煮物碗 (9,8×8,2) 1117030551




170-401-741 **2,530**円 粉引おたのしみ蓋物 (10×72) 501710374



170-402-701 **2,320**円 錆十草福碗 (10.8×8.5) 501710571



170-403-741 **2,730**円 土物十草円菓子碗 (11×9.6) 501640174



170-404-741 **2,320**円 グリーン渦福碗 (10.8×8.5) 501710474



170-405-261 **2,000**円 漆黒円菓子 (φ10.1×8.8) 1117040526



170-501-701 **2,130**円 黄輝角煮物碗 (10×10×7.5) 916930570



170-502-741 **2,130**円 彩り水玉角煮物碗 (10×10×7.5) 916920574



170-503-601 **2,060**円 花紋ちらし円菓子碗 (10.8×10) 501740260



170-504-601 **1,620**円 白化粧 反り型小円菓子碗 (10.7×8) 501650760



170-505-601 **1,620**円 青磁 反り型小円菓子碗 (10.7×8) 501650560

171-101-261 **4,700**円 錦宝来円菓子碗 (11.8×7.7) 815730126



171-102-781 **4,860**円 黒金唐草円菓子碗 (11.5×7.8) 501520278



171-103-261 **4,600**円 obi 円菓子 (ф12×8.7) 1016820526



171-104-051 **4,500**円 総紋小花煮物碗 (11.8×8.5) 501330105



171-105-051 **4,000**円 古染閑人蓋物 (10.5×10.5×10.5) 501230305



171-201-781 **3,980**円 ラスター華々煮物碗 (11.5×9.5) 816120578



171-202-341 **3,850**円 高麗花彫煮物碗 (12.5×9) 501520334



171-203-511 **3,850**円 赤釉銀彩刷毛 煮物碗 (11,4×8.7) 1117120351



171-204-351 **3,550**円 信楽金銀彩蓋物 (13×9.5) 815710235



171-205-301 **3,300**円 曙小煮物碗 (11.6×9) 501740130



171-301-251 **3,600**円 赤絵花鳥菓子碗 (12.8×9) 715120325



171-302-511 **3,300**円 赤絵丸紋円菓子碗



171-303-251 **3,300**円 唐草円菓子碗



171-304-511 **2,600**円 二色吹 煮物碗 (11.4×8.7) 1117130451



171-305-511 **2,600**円 三色吹 煮物碗 (11.4×8.7) 1117130551



171-401-701 **3,260**円 ピンク吹円菓子碗 (11.5×7.8) 501740371



171-402-781 **3,150**円 黄彩円菓子碗 (12.2×9.4) 501640478



171-403-741 **3,150**円 緑彩円菓子碗 (12.2×9.4) 501640374



171-404-781 **2,710**円 ヒワ磁一珍十草 円菓子碗 (_φ12.3×10.5) 1117140478



171-405-331 **2,800**円 呉須椿 煮物碗 (11.7×11.3) 815720233



171-501-701 **2,710**円 梨地唐草円菓子碗 (φ12.3×10.5) 1016910270



171-502-701 **2,650**円 彫唐草円菓子碗 (12.3×10) 501640571



171-503-701 **2,440**円 一珍青花円菓子碗 (12.3×10) 501650371




171-504-601 **1,840**円 青磁 反り型円菓子碗 (12.8×9) 501650460




171-505-601 **1,840**円 白化粧 反り型円菓子碗 (12.8×9) 501650660









172-101-741 **6,080**円 赤巻唐草平蓋向(16.7×9) 501410374




172-102-701 **5,740**円 黒金唐草平蓋向(16.7×9) 501410471



172-103-741 **5,720**円 赤絵万暦蓋向(16×10) 501410274



172-104-701 **5,740**円 彩光ライラック蓋向(φ16.7×9) 1017040370




172-201-251 5,250円 金緑彩蓋向(13.3×8.3) 501510125




172-202-261 **5,000**円 友禅菊蓋向(14.3×8) 815830326



172-203-511 **4,850**円 金彩黒油滴平蓋向(17.1×9.1) 917010451



172-204-511 4,650円 ヒワグリーンラスター平蓋向(17.1×9.1) 917020151




172-301-741 **4,530**円 赤絵波千鳥蓋向(14.4×8) 815630174




172-302-701 **4,520**円 赤間取十草蓋向(14.4×8.3) 815620170



172-303-741 **4,250**円 土物十草平蓋向(17.8×8.7) 501420274




172-304-781 **3,950**円 金吹雪蓋向(15×7.5) 501310178




172-401-781 **3,760**円 ピンク吹平蓋向(16.7×9) 501430178



172-402-781 **3,760**円 吹墨平蓋向(16.7×9) 501420478



172-403-741 3,650円 梅づくし蓋向(16.8×8.5) 501440177



172-404-261 **3,600**円 二色吹き蓋向(16.5×8.8) 917020326



173-101-301 **3,800**円 万暦蓋向(13.2×7.6) 917110130



173-102-781 **3,150**円 緑彩平蓋向(16.7×9) 501430378



173-103-701 **3,150**円 黄彩平蓋向(16.7×9) 501440371



173-104-601 **2,540**円 花紋ちらし蓋向(16.5×9) 501450460



173-201-741 **3,430**円 染付釉蓋物(11.5×7.5) 501730174



173-202-251 **3,300**円 粉引刷毛煮物碗(13.3×6.2) 501540325



173-203-781 **3,150**円 緑彩蓋向(丸)(15×9) 501440477



173-204-341 **2,800**円 乾山赤画煮物碗(13×8) 501530434



173-301-051 3,700円 現代織部蓋物(14×14×7.5) 501340205



173-302-251 3,100用 流水角蓋物(12.5×12.5×8.5) 1117330225



173-303-701 **3,400**円 青白磁流水蓋向(16.8×6) 1117330370



173-304-701 **3,150**円 鉄仙花流水蓋向(16.8×6) 1117330470



173-401-341 **8,250**円 一珍牡丹8.0骨むし(24.5×12) 501550534 173-402-341 **5,600**円 一珍牡丹7.0骨むし(21.5×10) 501550634



173-403-301 **6,350**円 十草赤丸紋骨むし(21.3×9) 501550330 173-404-301 **4,000**円 十草赤丸紋平蓋向(16.2×8.5) 501550430